



## TWIN PUMP STATION GENERAL ARRANGEMENT DETAILS



**SECTIONAL PLAN OF GRP TANK**

## PACKAGED PUMP SYSTEM SITE DETAIL SHEET

**Please complete the table below and indicate the positions of the inlet(s) on the plan below. Manufacture of the pump station cannot commence until this sheet is completed, signed and returned.**

Client .....

Site Address.....

.....

.....

.....

.....

SPS Contract Ref.....

Tank Diameter "A".....

Tank Depth "B".....

Inlet Height "C".....

Discharge Depth "D".....

**Inlet Positions Please mark on Plan View**

Inlet Diameter's (OD).....

Inlet Material.....

Number of Inlets.....

**Discharge Position at 12 O'clock as Standard**

Discharge Diameter's (OD).....

Discharge Material .....

Number of Pumps.....

Site Contact.....



Telephone.....

Client Signature.....

Print..... Site

Position.....

Plan View Side Elevation



## PUMP CHAMBER INSTALLATION GUIDE HEALTH & SAFETY AT WORK 1974

---

As with all site work the dangers of working with water and electricity pose severe threats to health if obvious and fundamental precautions are not taken. Therefore if you are in any doubt to any of the following, please don't hesitate to contact us.

All site work should be undertaken by qualified personnel only.


### TANK INSTALLATION

- 1) Select a suitable location for the tank. This will be normally at ground level lower than the properties being drained and allow for the falls in site drainage.
- 2) Check that no other structure – or special access – is required over the selected spot. Provision can always be made, if necessary, to place the tank on a roadway, provided that protective backfill is placed around it and a suitable heavy-duty manhole cover is used over the opening.
- 3) Check that no underground cable, pipe or service duct, lies underneath.
- 4) Excavate the minimum opening in the ground to receive the pumpwell and pipework to be used. If a machine is used to remove the spoil, the sides of the excavation should be battened for stability and a sump left in one corner for dewatering purposes.
- 5) The depth of excavation needs to be at most 500mm deeper than the overall tank depth. If it is dug by hand, the sides will require shoring up for safety, to prevent earth slippage.
- 6) A dewatering pump **MUST** be used to control any ground water present until the concrete backfill is set.
- 7) Some clean hardcore should be placed and consolidated in the base of the excavation. Usually this will need to be about 200mm thick, but in good ground, should be a minimum of 50mm.
- 8) Place in position the mass concrete base, minimum thickness 150mm of CP 20Kn/mm<sup>2</sup> strength.
- 9) Lower the pumpwell onto the damp concrete allowing the base flange, if fitted, to settle in, ensuring that the inlet and outlet pipes are correctly aligned.
- 10) Place further mass concrete, as before, at least 150mm thick around the pumpwell to just below the level of the lowest inlet. Consolidate the concrete, being careful not to damage the tank or tank inlet/outlet pipes.  
***The concrete backfill is designed to protect the chamber from external ground and water pressure. Therefore we cannot accept responsibility for damage to the chamber caused by ground or water pressure after installation.***
- 11) Connect up the site pipework to the inlet and outlet of the pumpwell and install draw cables through the conduit to the control panel.
- 12) Backfill around the pumpwell with more concrete, remembering to fill the tank with clean water to overcome the effect of buoyancy.

Sales 020 8991 6650 | Fax 020 8997 0199 | Internet [www.southernpumpservices.co.uk](http://www.southernpumpservices.co.uk) | Email [sales@spse.co.uk](mailto:sales@spse.co.uk)

Registered Office:  
28 Second Cross Road  
Twickenham  
Middlesex TW2 5RF

- 13) Finish off the surface of the concrete at the required level, depending on the final ground cover required i.e. topsoil, tarmac, gravel etc.  
 (see sketch below figures 1 and 2)



## IMPORTANT NOTES

All ground conditions should be checked prior to commencement of the excavations to access the suitability of the proposed installation.

It is **important** that once the tank is installed with the inlet / outlet connections made that the drainage system is flushed through and all sand / **debris is removed from the chamber prior to commissioning.**

**Steel mesh reinforcement** may be required to strengthen the concrete **surround** to the pumping chamber.

A Structural Engineer should be consulted concerning this.

If vehicular traffic will be passing over the chamber, it is **ESSENTIAL** that the cover slab is constructed so that there is **NO DIRECT LOAD** on the chamber. Also an access cover with the correct specified **S.M.W.L.** must be used.

A cable duct is required with **no sharp bends**, minimum size 80mm. ID

**PLEASE ALLOW THE CONCRETE BACKFILL TO SET BEFORE PUMPING OUT THE WATER IN THE PUMP CHAMBER**

## ELECTRICAL INSTALLATION

Wiring diagrams are enclosed with each control panel, please adhere to the diagram supplied.

## ADDITIONAL NOTES

The tank is **only off-loaded on site** and we do not install the **tank insitu**. This should either be carried out by **the main contractor** or by our specialist **sub-contractor** by prior arrangement.

**WE RECOMMEND THAT ONCE THE SYSTEM HAS BEEN COMPLETELY INSTALLED, OUR ENGINEER ATTEND THE SITE TO COMMISSION THE SYSTEM.**

**If any further information is required please contact Southern Pump Services Limited – 0208 991 6650**